



**824-IUG-24**

ALIGN WITH  
HANDLE  
IMBEDDED  
SCREW

SLOTTED HEAD  
SCREW DRIVER  
(NOT INCLUDED)

SHAFT OF  
STANDARD  
SERIES 24 SWITCH  
(SWITCH NOT SHOWN)

CUSTOM  
ALIGN & PUSH  
SERIES 24 SWITCH  
SHAFT COLLAR

CUSTOM SERIES 24  
PUSH HANDLE

1. REMOVE OLD SWITCH HANDLE
2. ALIGN FLAT OF COLLAR WITH SWITCH SHAFT AND SLIDE OVER SWITCH SHAFT  
MAKE SURE "ALIGN & PUSH" WORDING FACES HANDLE AS SHOWN
3. ALIGN HANDLE WITH SWITCH SHAFT AND PUSH ONTO SHAFT
4. USE SCREW DRIVER (NOT INCLUDED) TO INSTALL SCREW HANDLE ONTO SWITCH SHAFT

SWITCH NOT SHOWN

SECOND PUSH  
HANDLE IN  
TOWARD  
COLLAR

FIRST ALIGN  
HANDLE ARROW  
VERTICAL TO  
COLLAR ARROW

THIRD TURN HANDLE TO  
ACTIVATE SWITCH  
WHILE CONTINUING  
TO PUSH TOWARDS COLLAR

SWITCH NOT SHOWN

360° IN EITHER DIRECTION

REVISIONS:

REV  
0